

PackDot



FlexoStore

A decorative graphic below the text 'FlexoStore' consisting of a grid of squares and circles in various shades of gray and black.

This page is intentionally left blank



TABLE OF CONTENT

1)	INTRODUCTION	5
2)	MAIN SCREEN	5
3)	MICROSCOPE COAXIAL	7
4)	MICROSCOPE WIFI	11
5)	REPORT & SHARING	14
6)	TOOLS SCREEN	15
7)	SETUP	16
8)	IMPORTANT INFORMATIONS	17
9)	LOGING	18
10)	APPENDIX A (Microscope Coaxial mount)	19
11)	APPENDIX B (Microscope WiFi mount)	20
12)	APPENDIX C (Calibration)	21

This page is intentionally left blank


1. INTRODUCTION

The first APP access, will show the screen with the terms of use, if you accept the terms, the APP will start.




2. MAIN SCREEN



One info is necessary to create a new record for the inventory: **JOB name or JOB code**. To star a Job record, tap the plus (+) icon on the 1st screen.



Tap on the record and access the detail screen. To complete the inventory, tap icon microscope or 4-colors wheel. If you slide a record, can to delete the record.




Description of Tools


	<p>Plus: Adds a new record</p>
	<p>Search: Filter records by name, maker, date or time</p>
	<p>CMYK Wheel: Access the WIFI microscope operations (see appendix A to connect)</p>
	<p>Microscope: Access the coaxial microscope operations (see appendix B to use)</p>
	<p>PDF: Creates a pdf report, access the sharing of IOS (social networks as WhatsApp, iBooks etc) This a FULL report, includes two photos by record.</p>
	<p>PDF: Creates a pdf report, access the sharing of IOS (social networks as WhatsApp, iBooks etc). This a list report, without photos.</p>
	<p>Trash: Clean all fields</p>
	<p>Save: Adds or updates the record inventory</p>
	<p>X: Cancel and/or close the screen</p>


3. Microscope Coaxial


After attaching your smartphone to the microscope (see appendix A), tap the microscope icon. Take a photo, tap over two dots and save the result.




If the auto fill doesn't identify, two clean dots to form a perfect draw, try to use the B&W option. Tap the hand icon, B&W, adjust the tolerance and tap the dot.




On the first tap you have the diameter. Now you can inform the screening  (if you know), the APP calculates the percentage. Press M+ to put the result on the memory.




If the dots are not clear, you use the percent tool (%), tap two dots, as centered as possible, use the lateral slider to increase or decrease the diameter of the estimated dot outline. You can move the individual tool to improve the center.
















You can read the dot diameter manually, choose the tool microns, tap two times over the dot, drag to the border of the dot. The line on **I-I** help the correct tool application.








This sample shows the micro texture and dot diameter. Here you can use .

Tools description



	Play: start the camera, if icon lock appears, log in
	Camera: take a picture
	Zoom: increases or decreases the camera zoom
	Status: shows magnification or results after using the tools
	Sliders: modify the tolerances like lighting, brightness etc
	Tools: Check screen, dot diameter and percent.
	Trash: Clean all fields
	Save: Adds or updates the record inventory
	X: Cancel and/or close the screen
	Tap: Tap to measure, one or two dots required
	Line: shows what is being measured
	B&W: 1Bit image
	Line: Manual percent calculation (known screen)

4. Microscope WIFI



After connect your smartphone to the WIFI microscope (see appendix B), tap the 4 colors icon. Take a photo, choose the closest color filter, press calculate and save the result. Two dots tap calculate the screening, percent and average diameter.









With the manual tools, you can quickly get the screening and percentage.


















For reading flexo plates, use the led table, turn to minimum the microscope light. If the dots are very small, use the tool cross. Position the tool on the point and double click, do the same in a neighbor dot.



Cross & Tap tool are very easy to use. Manual tools too can be used here.




Tools description






	Play: start the camera, if icon lock appears, log in
	Camera: take a picture
	Pinch: increases or decreases the camera zoom
	Status: shows magnification or results after using the tools
	Sliders: modify the tolerances like lighting, brightness etc
	Tools: Check screen, dot diameter and percent.
	Trash: Clean all fields
	Save: Adds or updates the record inventory
	X: Cancel and/or close the screen
	Tap: Tap to measure, one or two dots required
	Manual Tools: Active manual measurement tools
	Zoom: inform lens magnification used
Touch on Status Bar	Manual percent calculation (known screen)
	Calcule: press after applies some color filter, auto calculation of the percentage.
	Cross: Allow the double tap tools, used to small dots
	Filters: Auto color separation

5. Report & Sharing

Very simple, on the job screen, just tap the PDF or email icon, blue icon send a complete report, with photos (see sample below). Green icon send a short report without photos.




Description of Tools

	<p>PDF: Creates a pdf report, access the sharing of IOS (social networks as WhatsApp, iBooks etc) This a FULL report, includes two photos by record.</p>
	<p>PDF: Creates a pdf report, access the sharing of IOS (social networks as WhatsApp, iBooks etc). This a list report, without photos.</p>
	<p>email: send the report directly to email</p>
	<p>PDF: send the report for social medias or Ibooks</p>
	<p>Back: Return to inventory screen</p>


6. Tools Screen

In addition to the basics for any APP, such as About, Copyright and Help, here 's some important tools such as Backup (DropBox™ or by email) and database cleanup.

The email backup creates an email with all pictures and the database, but this can be limited by your email account bytes by email X number of records by job.



Tap the DropBox™ icon, login or sign in, allow the transfer and do the backup















The ClearALL button only becomes available after a full Backup confirmed and transferred to DropBox™.

7. Setup

Its operation is very intuitive

Description of Tools

	Tube microscope standard lens
	Auto Focus (not for this version)
	Screening unit
	Thickness unit
	WiFi microscope ever on (not for this version)
	WiFi microscope standard lens
	Copy photos to phone album
	Mute shutter
	BLE printer (not for this version)
	DataShow presentation touch position
	Lens Calibration
	Reset for factory values

8. Important Informations

This APP was written to work correctly with the PackDOT kit, a hardware sold by FlexoStore, see our web site. This kit consists of:


<i>Software Database License – login limited</i>	<i>1</i>
<i>Software WIFI microscope License – login limited</i>	<i>1</i>
<i>Software Tube Microscope – login limited</i>	<i>1</i>
<i>Coaxial microscope</i>	<i>1</i>
<i>WIFI microscope</i>	<i>1</i>
<i>Microscope base</i>	<i>1</i>
<i>Microscope Phone adapter</i>	<i>1</i>
<i>Microscope stand</i>	<i>1</i>
<i>LED table</i>	<i>1</i>
<i>Case + keys</i>	<i>1</i>
<i>Calibrator</i>	<i>1</i>
<i>Extend battery</i>	<i>1</i>

9. Login – Sign UP

It is necessary to use all APP functions like CAMERA (WiFi and Tube microscope).

1st sign up to create an account, your account will be checked, only buyers of our toolkit will have the account approved.

When your account is approved, once logged in, you will have green lights such the sample below. Otherwise, you can use all functions less the camera, for try the APP tools, reports etc.



10. APENDIX A





- 1 – replace the rubber cap with the adapter;
- 2- Are two adapters type, fixed or universal, see below the correct way to mount;
- 3- For universal, adjust the center of the adapter with center of the camera.




11. APENDIX B

- 1 - Turn the microscope on, to read press, set the light to maximum;
- 2 - To read plates, try the led light box, this will improve the contrast;
- 3 - Set the microscope light to minimum, turn on the box light.




12. Calibration


- 1 – Create a new job, named AUTOCAL
- 2 – Using a stage micrometer, zoom at show 100 microns distance bars on the screen



- 3 – With screening tool, tap 1st and 2nd bar, double tap the circles to auto identify
- 4 – The calibration will be auto calculated, confirm or dismiss the new value



5 – WiFi 200x uses the same process, here using a standard ruller to calibrate



6 – WiFi 10x calibration with a standard ruller

